

## THANK YOU

Thank you for purchasing our FerroForcia parts!

## PACKAGE CONTENT

Part number	Quantity	Description
HSH1-001-U	1	2x hinge 2x pin 2x bush 2x grease nipple 2x blind cap

## PAINTING/ASSEMBLY LIST

Before painting and mounting the hinges onto your Defender, first check the instructions as described in our [Painting/Assembly list](#).

## MOUNTING VIDEO

Besides the mounting instruction below, we also have a mounting video available. Scan the QR-code or go to our website [www.ferroforcia.com/product/hsh1-001-u/](http://www.ferroforcia.com/product/hsh1-001-u/)



## MOUNTING INSTRUCTION

- 1 Remove the hood, pop-up and take it off.
- 2 Disassemble the old hinges from the hood.
- 3 Clean the spots on the hood where the new hinges will be mounted.
- 4 Mount the FerroForcia hinges onto the hood
  - a) Take bolt with ring and filler plate on top
  - b) Place the hinge and manually give all bolts a few twists
  - c) Repeat step a) and b) for the other hinge
  - d) Make sure the hinges are not tightened yet! A few manual twists are okay for now
- 5 Make sure the bushes are in place and assemble the hood back on the Defender
- 6 Now put the steel pins through the hinges and frame eyelets with bush. Tighten the steel pins.
- 7 Open the hood and now secure the 3 screws tightly for each hinge.
- 8 Close the hood and make sure it's fixed.
- 9 Insert grease nipples onto the hinges and grease the hinge.
- 10 If you prefer, you can replace the grease nipples (after greasing!) with the blind caps which are included.