

THANK YOU

Thank you for purchasing our FerroForcia parts!

PACKAGE CONTENT

Part number	Quantity	Description
HSH1-001	1	2x hinge 2x pin 2x bush 2x grease nipple 2x blind cap

MOUNTING VIDEO

Besides the mounting instruction below, we also have a mounting video available. Scan the QR-code or go to our website <https://ferroforcia.com/product/hsh1-001/>



MOUNTING INSTRUCTION

- 1 Remove the hood, pop-up and take it off.
- 2 Disassemble the old hinges from the hood.
- 3 Clean the spots on the hood where the new hinges will be mounted.
- 4 Mount the FerroForcia hinges onto the hood
 - a) Take bolt with ring and filler plate on top
 - b) Place the hinge and manually give all bolts a few twists
 - c) Repeat step a) and b) for the other hinge
 - d) Make sure the hinges are not tightened yet! A few manual twists are okay for now
- 5 Make sure the bushes are in place and assemble the hood back on the Defender
- 6 Now put the steel pins through the hinges and frame eyelets with bush. Tighten the steel pins.
- 7 Open the hood and now secure the 3 screws tightly for each hinge.
- 8 Close the hood and make sure it's fixed.
- 9 Insert grease nipples onto the hinges and grease the hinge.
- 10 If you prefer, you can replace the grease nipples (after greasing!) with the blind caps which are included. Make sure to keep the grease nipples, for when you need to grease again!